



Towbar Fitting Instructions
To Suit MITSUBISHI MAGNA WAGON 87-3/92
Part Number CL39A
Rating 1200Kg

1. Ensure all hardware items have been included.
2. Unhook muffler.
3. Remove exhaust bracket from body.
4. Remove and discard bracket from end of muffler.
5. Remove shipping hook from driver's side rear panel.
6. Remove shipping hook from passenger side.
7. Lift towbar into position and bolt it to vehicle.
8. Bolt rubber supporting exhaust bracket removed from body to bracket welded on towbar.
9. Bolt loose exhaust bracket provided to end of muffler.
10. Hook rubbers on brackets.
11. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit MITSUBISHI MAGNA WAGON 87-3/92
Part Number CL39A
Rating 1200Kg

