

Towbar Fitting Instructions
To Suit MITSUBISHI LANCER WAGON 9/92
Part Number CL49A
Rating 750Kg

1. Ensure all hardware items have been included.
2. Remove tow hooks.
3. Remove spare wheel.
4. Lift towbar into position being careful not to squash wiring loom.
5. Fit longer bolts supplied into tow hook holes.
6. Tighten all bolts to torque listing below.
7. Rotate spare wheel carrier attachment hook around 180° to clear towbar.
8. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

