



Towbar Fitting Instructions  
To Suit MITSUBISHI VERADA 10/96- 9/05  
Part Number CL57B  
Rating 1500Kg

1. Ensure all hardware items have been included.
2. Remove panel trims from inside boot.
3. Unclip exhaust of rubber mounting at rearward most muffler and let hang.
4. Remove heat shield.
5. Remove rear bumper bar.
6. Hold towbar up to vehicle and fit two M10 fine thread bolts with washers into captive nuts inside of chassis. Do not tighten - one each side.
7. Fit tapped plate on wire through large hole in bottom of chassis and fit bolt and washer - one each side.
8. Tighten these four bolts.
9. Cut bumper as per diagram.
10. Refit bumper bar. (**NOTE:** Replace rearward most bumper bar mounting bolts with longer bolts supplied.)
11. Refit heat shield.
12. Refit exhaust.
13. Refit rear trims.
14. Tighten all bolts to torque listing below.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions  
To Suit MITSUBISHI VERADA 10/96- 9/05  
Part Number CL57B  
Rating 1500Kg

