

# TRAILBOSS

## Towbar Fitting Instructions To Suit MITSUBISHI MIRAGE Part Number CL59 Rating 750Kg

1. Ensure all hardware items have been included.
2. Hold towbar into position aligning holes in side of chassis with holes in towbar and support with jack.
3. Insert bolts through towbar into chassis.
4. Insert tapped plates through large slots in bottom of chassis and fit bolts. Do not tighten.
5. Fit bolt, plate and washer through shipping hook. Do not tighten.
6. Ensure towbar is square to vehicle and tighten all bolts to torque listing below.

### **RECOMMENDED ASSEMBLY TORQUE LISTING**

| <b>Diameter</b> | <b>Grade 8.8 Bolt</b> |
|-----------------|-----------------------|
|                 | <b>Nm</b>             |
| M6              | 9.5                   |
| M8              | 21.7                  |
| M10             | 43.4                  |
| M12             | 77.3                  |
| M14             | 121.0                 |
| M16             | 189.8                 |

