

TRAILBOSS

Towbar Fitting Instructions To Suit NISSAN PULSAR ALL HATCHBACK MODELS 10/91-ON Part Number DS70A Rating 850Kg

1. Ensure all hardware items have been included.
2. Remove shipping hooks, one each side.
3. From under car remove plastic screw from centre of bumper.
4. Feed towbar up on exhaust side first, then by pulling bumper rearward feed crosstube in between bumper and spare wheel well, lining up with shipping hook tapped holes.
5. Fit bolts supplied.
6. Tighten all bolts to torque listing below.
7. Refit bumper screw.

NOTE:

On some two litre models it may be necessary to modify outside rear exhaust rod arm by supporting muffler with jack and bending away from towbar side arm after fitting of towbar.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

