

TRAILBOSS

Towbar Fitting Instructions To Suit NISSAN PULSAR HATCH Part Number DS74A Rating 900Kg

1. Ensure all hardware items have been included.
2. Remove and discard shipping hook on passenger side.
3. Fit three bolts on wires through end of chassis and into existing holes on driver's side.
4. Lift towbar into position drivers side first and then passenger side.
5. Fit bolts and washer. Do not tighten.
6. Fit remaining nuts and washers on drivers side.
7. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

