



Towbar Fitting Instructions
To Suit DAEWOO LANOS 2&4 DOOR HATCH 97-ON
Part Number DW7
Rating 1100Kg

1. Ensure all hardware items have been included.
2. Fold rear seat forward.
3. Fold rear carpet and masonite lid forward.
4. Remove spare wheel.
5. Using sketch provided, mark and drill rear panel using 11mm drill.
6. Remove two plastic trim buttons holding bottom flange of bumper bar.
7. While holding bottom flange of bumper rearward, lift towbar into position so as angle mounting brackets fit in between bumper and rear panel.
8. Align holes in angle mounting brackets with holes drilled in steps.
9. Fit bolts loose plates semi tight.
10. Fit tapped loose plate on top of shipping hook and fit bolt through 12mm hole in saddle into tapped loose plate.
11. Tighten all bolts to torque listing below.
12. Using holes in tail as guide, mark spare wheel well using centre punch.
13. From inside boot, drill centre punch marks to 11mm fit loose plates and bolts. Tighten to torque listing.
14. Refit spare wheel and masonite lid and fold carpet forward.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit DAEWOO LANOS 2&4 DOOR HATCH 97-ON
Part Number DW7
Rating 1100Kg

