



Towbar Fitting Instructions
To Suit Holden Rodeo 2 X 4 Utility
Part Number HD30-31A
Rating 1000Kg

1. Offer the towbar to the vehicle and secure to the outside of the chassis rails using ½” x 1 ½” unc bolts, flat washers, spring washers and nuts. (Items 1, 3, 3, 2 and 4).
2. Using the forward lower mounting hole on either side of towbar as a guide, drill a 13mm hole through the chassis and secure with ½”x 1 ½” unc bolts, flat washers, spring washers and nuts. (Items 1, 3, 3, 2 and 4).
3. Tighten all bolts to the correct torque setting as listed.

COMPONENT KIT

<u>ITEM</u>	<u>DESCRIPTION</u>	<u>QTY</u>	<u>TORQUE Nm</u>
1	½” x 1 ½” unc bolt	6	125
2	½” spring washer	6	
3	½” flat washer	12	
4	½” unc nut	6	
5	Tongue, 10T	1	
6	5/8” x 1 ½” unc bolt	2*	249
7	5/8” spring washer	2*	

*Note: One of Items 6 and 7 are used to secure tongue to towbar for transit packaging.

Wiring Code

<u>Signal</u>	<u>Wiring Harness</u>	<u>RHS of Vehicle</u>
RH Turn	Green	Green/White
LH Turn	Yellow	Green/Black
Stop	Red	Red
Tail Light	Brown	Green/Red
Earth	White	Black

TRAILBOSS

Towbar Fitting Instructions
To Suit Holden Rodeo 2 X 4 Utility
Part Number HD30-31A
Rating 1000Kg

