



Towbar Fitting Instructions  
To Suit HONDA ACCORD 12/98-ON  
Part Number HN40  
Rating V4 - 1200KG  
V6 - 1500KG

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Remove rear muffler(s) off 2 rear most rubber hangers.
4. Remove bumper, (1 screw and 1 plastic trim button at each wheel arch, 2 plastic trim buttons at rear under side of bumper and 5 plastic trim buttons at rear top side under boot lid). Remove bumper and foam insert.
5. Hold towbar up to vehicle so as 2 holes in tail align with shipping hook, fit U bolt semi tight.
6. Fit jack on same to tail section so as tail is up against spare wheel well.
7. Using 2 rear most holes in rear mounting plate as guides drill two 11mm holes through upper and lower faces of impact beam fit bolt, spacer tubes as per drawing.
8. Using holes in tail arms as guides drill four 11mm holes into spare wheel well, fit bolts loose plates etc. as per drawing.
9. Tighten all bolts to torque listing below.
10. Cut foam bumper insert to fit around towbar and refit.
11. Cut bumper as per sketch provided and refit.
12. Refit exhaust and spare wheel.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

# TRAILBOSS

Towbar Fitting Instructions  
To Suit HONDA ACCORD 12/98-ON  
Part Number HN40  
Rating V4 - 1200KG  
V6 - 1500KG

