



Towbar Fitting Instructions
To Suit HYUNDAI GRANDEUR 9/99-ON
Part Number HY12
Rating 1300Kg

1. Ensure all hardware items have been included.
2. Remove the three rear most exhaust hangers.
3. Remove and discard four bumper iron to chassis bolts.
4. Lift towbar into position, driver's side first.
5. Fit four M10x35 1.25 pitch bolts, spring washer and flat washer as per diagram,
6. Fit M12x40 bolt, spring washer and tapped plate through centre shipping hook.
7. Tighten all bolts to torque listing below.
8. Using remaining holes in towbar as guides, drill 11mm through chassis and bumper bar irons.
9. Feed tapped plates on wire through access hole and fit M10x30 bolts and spring washer. Tighten to torque listing.
10. Refit exhaust hangers.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit HYUNDAI GRANDEUR 9/99-ON
Part Number HY12
Rating 1300Kg

