



Towbar Fitting Instructions
To Suit HYUNDAI LANTRA WAGON 96-ON
Part Number HY9A
Rating 850Kg

1. Ensure all hardware items have been included.
2. Remove interior trim from rear and side panels to expose tail light assemblies.
3. Remove tail light assemblies.
4. Remove rear bumper bar.
5. Remove inner bumper beam, complete with brackets, from outer skin.
6. Remove and discard bumper mounting brackets.
7. Fit towbar into beam and secure with bumper mounting bracket bolts.
8. Refit beam/towbar assembly onto outer skin.
9. Refit bumper bar.
10. Fit plate and bolt to shipping hook mount.
11. Tighten all bolts to torque listing below.
12. Refit tail lights and interior trim.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit HYUNDAI LANTRA WAGON 96-ON
Part Number HY9A
Rating 850Kg

