



Towbar Fitting Instructions

To Suit FORD LASER HATCH TX3, TX3 4WD TURBO &
4 DOOR SEDAN MAZDA 323 SEDAN, HATCH 4 DOOR & ASTINA 3/90-9/94
Part Number MA49A

Rating 650Kg

1. Ensure all hardware items have been included.
2. Remove bumper bar.
3. Hold towbar in position and fit two 10mm bolts supplied in bottom inside holes (drill holes if necessary).
4. Making sure rest of holes line up with holes in car tighten two 10mm bolts.
5. Refit bumper with six 8mm whiz nuts supplied.
6. Use longer 8mm bolts supplied with plates and spring washers in bottom outer holes if required.
7. Reposition number plate approximately 25mm higher so that towbar does not interfere with number plate.
8. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions

To Suit FORD LASER HATCH TX3, TX3 4WD TURBO &
4 DOOR SEDAN MAZDA 323 SEDAN, HATCH 4 DOOR & ASTINA 3/90-9/94
Part Number MA49A

Rating 650Kg

