



Towbar Fitting Instructions
To Suit MAZDA MPV 9/99-ON
Part Number MA62
Rating 930Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Remove shipping hooks on each side, retaining six bolts.
4. Align towbar with horizontal shipping hook holes.
5. Fit six retained shipping hook bolts with spring washers supplied semi tight.
6. Making sure towbar is square to vehicle, drill two 11mm holes using centre mounting tabs as guides.
7. Remove rubber grommets next to centre mounting tabs. Fit bolts on wire through holes. Fit nuts, spring washers and tighten all bolts to torque listing.
8. Refit rubber grommets and spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit MAZDA MPV 9/99-ON
Part Number MA62
Rating 930Kg

