

Towbar Fitting Instructions

To Suit MITSUBISHI PAJERO LWB MODELS WITH COIL SPRINGS ONLY 5/91-ON

Part Number QT460E

Rating 2500Kg

1. Ensure all hardware items have been included.
2. Hold towbar up to chassis and align rear most holes in chassis.
3. Fit two M12 bolts with loose plates and washers into tapped holes in chassis semi tight.
4. Remove tail lights in bumper by removing four short Philips screws.
5. Fit two M10 bolts in rear most holes using tapped plates supplied.
6. Tighten all bolts to torque listing below.
7. Remove bolt from rear most exhaust mount bracket.
8. Bolt extension bracket to rubber mounting bracket with original bolt, and nut supplied.
9. Bolt exhaust to extension bracket using bolt supplied as per diagram and tighten.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

