

Towbar Fitting Instructions To Suit Toyota Hilux Ute Bodies With Rear Step Part Number QT555L

04 / 2005 – 08 / 2011 Rating 2250 kg - 225 kg 09 / 2011 onwards Rating 2500 kg - 250 kg

WARNING:

Do not, drill, cut, weld or otherwise modify the Towbar.

If you are using electric welding on a motor vehicle, <u>always</u> check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could <u>destroy</u> any onboard <u>computers</u>. If in doubt, check with the vehicle's manufacturer.

- Ensure all hardware items have been included.
- 2. Remove rear step from vehicle place step on suitable stands to support.
- 3. Remove side arms that support step each side.
- 4. Refit arms with 8mm packers provided each side.
- 5. Discard original bolts that fasten step to chassis rails 4 in total.
- 6. Offer Towbar to chassis rails aligning holes in side plates with captive nuts in chassis rails.
- 7. Fit M12 x 1.25 bolts flat & spring washers to front most mounting hole on each side of the side plate loosely.
- 8. Feed bolts on wire up chassis rails 2 per side then feed through existing holes.
- 9. Refit step sliding step forward to align holes in brackets with holes in side plate s of Towbar then fasten with M12 x 1.25 bolts & flat & spring washers provided.
- 10. Fasten all bolts & nuts to torque listing below.
- 11. Trim excess wire off bolts on wire that have been fed down the chassis rails.
- 12. Note T/BM 21177 to be in the DOWN position for 4x4 and in the UP position for 4x2 models.


RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	eter Grade 8.8 Bolt	
	Nm	
M6	9.5	
M6 M8	21.7	
M10	43.4	
M12	77.3	(M12 Grade 10.9 Bolt = 120 Nm)
M14	121.0	,
M16	189.8	



Towbar Fitting Instructions To Suit Toyota Hilux Ute Bodies With Rear Step Part Number QT555L

04 / 2005 – 08 / 2011 Rating 2250 kg - 225 kg 09 / 2011 onwards Rating 2500 kg - 250 kg



QTY.	DESCRIPTION	ITEM NO.
1	WELDED ASSEMBLY	1
1	TRAILER BALL MOUNT	2
1	BOLT PACK	3
2	LOOSE PLATE	4
4	BOLT & WIRE ASSEMBLY	5
1	M10x1.5 HEX NUT PC8	6
1	BOLT M10-1.50 x 25	7
4	BOLT M12 - 1.25 x 45mm Gr 10.9 Z/P	8
8	Wshr spring ft sec M12x4.0x2.5mm z/p	9
8	WASHER M12x28.8x3mm	10
4	M12x1.75 HEX NUT PC8	11
1	BRAND BAG ASSY	12
1	PLASTIC SHEET BAG 250x350	13
1	FITTING INSTRUCTION	14
1	ACRYLIC CP LABEL	15
1	ACRYLIC LR LABEL	16
1	PULL PIN	17
1	R CLIP	18
1	HITCH BOX COLLAR COVER	19
1	WIRING LOOM	20



Wiring Loom Fitting Instructions To Suit Toyota Hilux Hilux Cab Chassis & Tub Body – 4x4 & 4x2

Part Number 100002-WL

Wiring Loom Installation Instructions

Toyota Hilux Hilux Cab Chassis & Tub Body – 4x4 & 4x2

Part No: 100002-WL

Tail Harness Length Required: 1800mm RPA Override Switch Part No: 04848 (If Fitted)

Wiring Loom Installation Time: Approx 20 Mins

Page 1 of 2

Issue Date 18-02-10

Email: info@cequent.com.au
Post: PO Box 4050, Dandenong South VIC 3175



Wiring Loom Fitting Instructions To Suit Toyota Hilux Hilux Cab Chassis & Tub Body – 4x4 & 4x2

Part Number 100002-WL

- 1. Disconnect and remove the tail light on both sides of the vehicle by removing the two fasteners on each tail light assembly.
- 2. From underneath the vehicle, route the Trailer Patch Harness (P/No:100002-WL) connectors up the RHS tail light cavity.
- 3. Patch the Trailer Patch Harness RHS connectors in between the tail light connectors.
- 4. Refit the RHS tail light assembly.
- 5. Underneath the vehicle, route the Trailer Patch Harness over the support bar and along the vehicle harness towards the LHS tail light cavity.
- 6. Retrieve the Trailer Patch Harness connectors.
- 7. On the Tail Harness (length 1800mm) and mating connector, apply electrical grease or silicon on to the back of the connectors to make them water proof.
- 8. Connect the Trailer Patch Harness tail connector and the Tail Harness connector together.
- 9. Reconnect the LHS tail lights and refit the tail light assembly.
- 10. Mount the Tail Harness socket to the towbar mounting plate using M4 fasteners.
- 11. Test the Trailer socket using a light board or multi-meter.
- 12. Secure the all harnesses using cables ties (not supplied). Refit all removed parts and secure all fasteners. Place instructions in glove box after fitment.

Page 2 of 2

Cequent Customer Service

Issue Date 18-02-10