

TRAILBOSS

Towbar Fitting Instructions
 To Suit TOYOTA LANDCRUISER STATION WAGON FJ62/HJ60-1985
 Part Number QT850B
 Rating 2500Kg

1. Ensure all hardware items have been included.
2. Remove shipping hook.
3. Remove rear air conditioning line retaining clip from Chassis on driver's side.
4. Lift towbar in position and align rear holes in angle sides with existing holes in chassis.
5. Fit plate and bolt assemblies, loosely
6. Screw in fine thread centre bolts.
7. Using holes in front ends of angle sides as guides, drill 12mm clearance holes.
8. Fit bolts.
9. Tighten all bolts to torque listing below.
10. Replace rear air conditioning line retaining clip.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>	<u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M14		121.0
M16		189.8

