



Towbar Fitting Instructions
To Suit NISSAN NAVARA D22 2WD 4WD
ALL MODELS EXCEPT DUAL CAB W/OUT STEP 86-ON
Part Number QTDS570A
Rating 3000Kg

1. Ensure all hardware items have been included.
2. Models with rear bumper bar - remove bumper bar.
3. Models with ute body - remove lower tailgate panel.
4. Insert inner chassis brace on inside of chassis rails.
5. Insert M10x30 bolts through chassis= existing hole into captive nut on brace - loosely.
6. Refit rear panel and refit bumper bar using original bracket and nut - loosely.
7. Lift towbar into position by locating most rearward hole in towbar side arm with most rearward holes in brace and chassis.
8. Models with no bumper bar - insert 3xM12x30 bolts/nuts through vertical face of chassis rail and brace - loosely.
9. Hold towbar towards rear of vehicle as far as possible and tighten rearmost 4 bolts to torque listings.
10. Using remaining 2 slots on side arms as guide drill 12mm hole on inner face of slots.
11. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit NISSAN NAVARA D22 2WD 4WD
ALL MODELS EXCEPT DUAL CAB W/OUT STEP 86-ON
Part Number QTDS570A
Rating 3000Kg

