

TRAILBOSS

Towbar Fitting Instructions
 To Suit FORD F250 TUB BODY & C/CHASSIS 2001-on
 Part Number QTFD1500
 Rating 3500Kg

1. Ensure all hardware items have been included
 2. To aid fitment spare wheel may need to be lowered.
- NOTE:-** If fitting towbar to c/chassis, disconnect tail lights before fitting towbar, as per following instructions. Feed wiring through access hole in towbar side plates before re-connecting tail lights.
3. Lift towbar into position and align holes in side plates with holes in bottom face of chassis.
 4. Fit bolts, loose plates, spring washers and nuts as per drawing.
 5. Tighten all bolts to torque listing below.
 6. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

