



Towbar Fitting Instructions
To Suit CHRYSLER JEEP CHEROKEE
PETROL & DIESEL MODELS WITH PLASTIC FUEL TANK 8/97-ON
Part Number QTJP8
Rating 2268Kg

1. Ensure all hardware items have been included.
2. Remove shipping hook from passenger side chassis rail.
3. Remove exhaust hanger from driver's side chassis rail.
4. Remove bolts and studs holding tank guard.
5. Remove tank guard.
6. Hold towbar up into position aligning holes in towbar side plates with tapped holes in chassis.
7. Using bolts supplied, fit most forward bolts semi tight.
NOTE: For vehicles fitted with over head console
Fit two most rearward bolts first, then fit remaining bolts and towbar on the outside of fuel tank guard.
8. Hold tank guard up into position and fit remaining bolts through tank guard and exhaust hanger.
9. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8



Towbar Fitting Instructions
To Suit CHRYSLER JEEP CHEROKEE
PETROL & DIESEL MODELS WITH PLASTIC FUEL TANK 8/97-ON
Part Number QTJP8
Rating 2268Kg

