



Towbar Fitting Instructions
To Suit SUZUKI SIERRA 4WD 1982-ON;
HOLDEN DROVER 1985-ON
DOES NOT FIT UTE
Part Number SU22
Rating 550Kg

1. Ensure all hardware items have been included.
2. Remove exhaust from exhaust bracket.
3. Remove and discard shipping hook.
4. Remove number plate complete with carrier.
5. Remove earth straps from petrol tank support on passenger side.
6. Cut off centre carrier bracket level with other two.
7. Lift towbar in position and bolt it to vehicle at the two centre bracket positions first.
8. Fit the rest of the bolts using shipping hook bolts on drivers side and new bolts supplied on passenger side.
9. Tighten all bolts to torque listing below.
10. Replace earth straps onto one of the number plate light retaining bolts.
11. Refit number plate without carrier, drilling new holes in number plate support brackets.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit SUZUKI SIERRA 4WD 1982-ON;
HOLDEN DROVER 1985-ON
DOES NOT FIT UTE
Part Number SU22
Rating 550Kg

