

# TRAILBOSS

Towbar Fitting Instructions  
To Suit SUZUKI VITARA 4 DOOR 1.6 LITRE ENGINE 88-ON  
Part Number SU31  
Rating 1000Kg

**NOTE: Will not fit Vitara with V6 motor.**

1. Ensure all hardware items have been included.
2. Remove shipping hook from chassis.
3. Hold towbar in position against chassis and fit four (4) longer bolts supplied.
4. Tighten all bolts to torque listing below.

## RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

