



Towbar Fitting Instructions
To Suit TOYOTA COROLLA 4 DOOR HATCH 6/89-9/94
Part Number TT100
Rating 850Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. On driver's side remove rear heat shield.
4. On passenger side remove nut and bolt holding shipping hook.
5. Fit towbar to car and support with a jack.
6. Fit original bolt and nut on passenger side.
7. Fit original nut on driver's side.
8. Using towbar as guide drill two holes into rear of spare wheel well.
9. Fit bolts and curved plates.
10. Using hole in forward arm open up hole to 10mm.
11. Remove one plastic cover plate and fit bolt inside subframe.
12. Slide plate on wire in through shipping hook hole and along chassis.
13. Fit bolt.
14. Tighten all bolts to torque listing below.
15. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit TOYOTA COROLLA 4 DOOR HATCH 6/89-9/94
Part Number TT100
Rating 850Kg

