



Towbar Fitting Instructions  
To Suit TOYOTA RAV 4 2&4 DOOR & CABRIO 7/90-ON  
Part Number TT117C  
Rating 1200Kg

1. Ensure all hardware items have been included.
2. Remove rear shipping hooks.
3. Lift towbar into position to align with shipping hook bolt holes.
4. Refit original bolts.
5. Tighten all bolts to torque listing below.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

