



Towbar Fitting Instructions
To Suit TOYOTA COROLLA SEDAN & WAGON 12/01-ON
Part Number TT131
Rating 950Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Remove rear most rubber grommet from spare wheel well.
4. Remove shipping hooks from both ends of sub frame.
5. Lift towbar into position so as to align with captive nuts and hole in spare wheel well.
6. Fit all bolts supplied as per diagram.
7. Tighten all bolts to torque listing.
8. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit TOYOTA COROLLA SEDAN & WAGON 12/01-ON
Part Number TT131
Rating 950Kg

