

# TRAILBOSS

Towbar Fitting Instructions  
 To Suit TOYOTA CRESSIDA SEDAN 11/88-ON  
 Part Number TT98A  
 Rating 900Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Remove rear panelling and carpet.
4. Release exhaust from rubber mounting rings.
5. Remove exhaust bracket from chassis.
6. Lift towbar into position against shipping hook on driver's side.
7. Fit bolts and nuts supplied.
8. On passenger side refit exhaust bracket over towbar using longer 8mm bolts supplied.
9. From under car, drill four (4) 11mm holes up through floor.
10. Fit loose plates and bolts.
11. Tighten all bolts to torque listing below.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

