

TRAILBOSS

Towbar Fitting Instructions
 To Suit TOYOTA COROLLA 4 DOOR SEDAN &
 4 DOOR SECA & HOLDEN NOVA 6/89-9/94
 Part Number TT99A
 Rating 850Kg

1. Ensure all hardware items have been included.
2. Fold carpet forward in boot.
3. Unhook muffler from rubber supports.
4. Using hacksaw blade or Stanley knife neatly cut two plastic tabs off bottom of bumper to allow towbar to go up into position.
5. Fit towbar between bumper bar and wheel well.
6. Support with a jack, making sure towbar is square on vehicle.
7. Drill two holes each side up into boot.
8. Open up the top holes only in boot to take spacer tubes.
9. Fit spacers, plates, bolts and nuts.
10. Tighten all bolts to torque listing below.
11. Refit exhaust.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

