

HAYMAN REESE
PART No: 03132W
RENAULT CAPTUR J87 SERIES

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED



Installation Time: Approx 90 Mins

Towbar Installation Instructions

Towbar capacity

RENAULT CAPTUR J87 SERIES

Part Number 03132W

Max Towing Braked 900 kg

Max Towing Unbraked 625 kg

Max Static Ball Load 75 kg

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

HAYMAN REESE

PART No: 03132W

RENAULT CAPTUR J87 SERIES

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLES'S GLOVEBOX AFTER INSTALLATION IS COMPLETED

Warning:

1. Do not, drill, cut, weld or otherwise modify the towbar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.
3. If TBM is used in inverted position tow ball may make contact with rear tailgate when lowered, which could cause damage.

General:

1. Ensure all hardware items have been included refer to assembly diagram.
2. It is recommended that the instructions are read through and completely understood before making any attempt to fit this product.
3. Be wary of any changes to vehicle designs or other accessories that may conflict with the installation of this product.
4. Before drilling ensure that the area is clear of fuel, electrical & other components.
5. All holes drilled into the body panels shall have all burrs & swarf removed then coated with a suitable rust preventative paint.
6. The high tensile fasteners supplied with this product were used to achieve the specified rating. If replacement is required ensure that fasteners of the same rating & quality are used. Contact an authorised **Hayman Reese** dealer if further information is required.
7. Ensure that all hardware is fastened to torque list below check fasteners on regular basis.
8. Towbar load rating sticker provided with this product shall be conspicuously located on inside rear end of the driver's door. **(See diagram below).**
9. Hayman Reese recommends that you check your tow ball to ensure that it complies with the Australian standards **AS 4177.2**.
10. **PLEASE NOTE:** It is advised to remove your LUG or TBM when not actually towing so as to produce a clear view of the vehicles registration plate if obscured, and to also provide maximum available departure angle.
11. Pull Pin must be fit in down position.


Tow bar Maintenance and Care.

Hayman Reese recommends that bolt torque's, as listed below, are routinely and regularly inspected and checked for correct tension. Replace any worn or defective parts.

We recommended to remove Tow Ball Mounts (TBM's, tongues or lugs) when not being used for any considerable length of time.

So as to avoid injury, when not towing it is suggested that the tongue, Pull Pin and R-clip are removed then stored in a safe, clean and dry place, away from excessive moisture.

Hitch Pull Pins and spring "R" clips are regularly checked for proper installation. Replace any worn or defective parts.



Place load rating sticker
inside driver's door here

FOR TOWING PURPOSES ONLY
For towing capacity details please refer to vehicle
owner's manual or to the manufacturer. Overloading can
void your warranties.


HAYMAN REESE

PART No: 03132W

RENAULT CAPTUR J87 SERIES

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED




| QTY. | DESCRIPTION | ITEM NO. |
|------|------------------------------|----------|
| 1 | RENAULT CAPTUR WELDED ASSY | 1 |
| 1 | SIDE ARM LHS | 2 |
| 1 | SIDE ARM RHS | 3 |
| 1 | LUG ASSY | 4 |
| 4 | NUT HX M10-1.25 Z/P | 5 |
| 8 | WASHER FT M10 X 25.4 X 3 | 6 |
| 4 | Ø42mm FITTING PLATE | 7 |
| 4 | SPACER TUBE 16 x 1.6MM | 8 |
| 4 | BOLT M10x100x1.25 | 9 |
| 2 | BOLT M16 x 45 2.0P | 10 |
| 2 | SPRING WASHER M16 X 5 X 3.5 | 11 |
| 1 | PLUG BRACKET | 12 |
| 2 | NUT NYLOC M4-0.7 Z/P | 13 |
| 6 | SET SCREW M12x45x1.25P | 14 |
| 12 | WASHER FLAT 1/2"x1 1/8"x1/8" | 15 |
| 6 | HEX NUT M12x1.25 PC8 | 16 |
| 1 | WIRING LOOM | 17 |
| 1 | HR TOWBALL | 18 |
| 2 | 10mm "D" SHACKLE | 19 |
| 1 | H.R STICKER | 20 |
| 1 | ACRYLIC COMPLIANCE PLATE | 21 |

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED

1. Release tail gate to expose boot space.




2. Remove 3 x Screws. Next to the tail light and directly below on the bumper.

Remove and disconnect tail lights. Repeat for opposite side.



3. Carefully peel away outer guard moulding to allow for bumper removal.


Remove push rivet securing bumper to rear guard. Repeat for opposite side.




INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLES'S GLOVEBOX AFTER INSTALLATION IS COMPLETED

4. Remove 3 x Screws. On the underside of the bumper near the tyre. Repeat for opposite side.




5. Remove 2 x Screws. Located on the centre and on the underside of the bumper.



6. Carefully remove bumper by peeling away at the edges and pull back on the centre of the bumper. Keep in a safe place for re-assembly.

Remove 4 x Flange Nuts on rear panel,
discard intrusion beam.



HAYMAN REESE

PART No: 03132W


RENAULT CAPTUR J87 SERIES

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLES'S GLOVEBOX AFTER INSTALLATION IS COMPLETED

7. Place both sidearms up against respective chassis rails. Use the 2 x M10 x 100 Screws, complete with Flat Washers, Washer Plate and Nut to loosely secure arms.

Note: On the passenger side chassis rail you are required to unbolt the exhaust hanger for fitment. Cut the tab section of the heat shield to allow for installation of the passenger sidearm. Re-install exhaust hanger.




8. Position centre section of the Towbar in relation to the side arms. Loosely secure using 6 x M12 x 45 Set Screws, complete with Flat Washers and Nuts.


Torque all fasteners to the specifications listed below:

M10 x 100 x 1.25P : 50Nm

M12 x 45 x 1.25P : 125Nm



9. Mark out and drill 2 x 5mm holes 69mm apart onto bumper skin to support plug bracket. Feed bracket threads through drilled holes prior to reinstalling bumper.



HAYMAN REESE


PART No: 03132W

RENAULT CAPTUR J87 SERIES

INSTALLATION INSTRUCTIONS

**PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED**

10. Re-Install bumper by following steps 1-5 in reverse order.



HAYMAN REESE
PART No: 100531-WL
RENAULT CAPTUR

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

Wiring Loom Installation Instructions

RENAULT CAPTUR

Part No: 100531-WL

ECU Required: 04826

Power Harness Required: 04825

Tail Harness Length Required: 1800mm

Wiring Loom Installation Time: Approx. 60 minutes

Important



Due to possible vehicle variations, always confirm any noted vehicle colour wires with a multi-meter to ensure the correct function is identified before soldering or scotch locking.

Issue Date 23-04-15

Page 1

Part No: 100531-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE
PART No: 100531-WL
RENAULT CAPTUR

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


1. On the rear luggage compartment, remove the floor carpet (1).
2. Remove the parcel shelf (2).



3. Fold the rear passenger seats (1) forward.
4. Remove the spare wheel carpet cover (2).



5. Remove the rear luggage trim (1).



Issue Date 23-04-15

Page 2

Part No: 100531-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

HAYMAN REESE
PART No: 100531-WL
RENAULT CAPTUR

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

6. Remove the RHS of the luggage compartment trim (1) by removing the two screws (2).


Repeat for the LHS.



7. On the LHS of the luggage compartment, carefully exposed the light connector (1) and disconnect.
8. Remove the LHS luggage compartment trim (2).



9. Remove the rear passenger LHS door trim (1).



Issue Date 23-04-15

Page 3

Part No: 100531-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE
PART No: 100531-WL
RENAULT CAPTUR


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

10. Remove the passenger LHS door trim (1).




11. Remove the LHS kick trim (1) and open the glove box (2) and remove the fuse panel.



12. At the LHS exterior rear quarter of the vehicle, remove the vehicle grommet (1) and drill the grommet hole out to Ø30mm. **Ensure the interior area is clear of obstructions before drilling.**

Note: If the vehicle grommet is occupied, drill into the sheet metal next to the grommet (2).

Apply rust inhibitor (not supplied) after drilling.



Issue Date 23-04-15

Page 4

Part No: 100531-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100531-WL


RENAULT CAPTUR

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

13. On the LHS of the luggage compartment, following the table below, connect the trailer patch ezy-taps (1) to the vehicle harness wires (2) and then connect the trailer patch terminals (3) to the corresponding wires (2).

| Function | Trailer Patch | Vehicle Connector |
|----------|----------------|-------------------|
| L.IND | YELLOW / BLACK | GREY / BLUE |
| REVERSE | BLACK / WHITE | PINK / WHITE |
| TAIL | BROWN / BLACK | BLUE |
| BRAKES | RED / BLACK | PINK |




14. On the LHS luggage compartment, using an alcohol wipe (not supplied), clean the inner sheet metal (1) as shown.
15. Connect the 12-way trailer patch connector (2) to the ECU (P/No: 04826) (3) and adhere the ECU (3) to the cleaned area on the inner sheet metal (1). **Ensure the ECU is mounted with the connector pointing downwards.**
16. Secure the trailer patch WHITE wire ground terminal (4) to the vehicle grounding point (5) using the existing fasteners.



17. Route the trailer patch along the rear of the luggage compartment towards the RHS of the luggage compartment.
18. On the RHS of the luggage compartment, following the table below, connect the ezy-tap (1) to the vehicle harness wire (2) and then connect the trailer harness terminal (3) to the corresponding wire (2).

| Function | Trailer Patch | Vehicle Harness |
|----------|---------------|-----------------|
| R. IND | GREEN / BLACK | WHITE / BLACK |



Issue Date 23-04-15

Page 5

Part No: 100531-WL

Hayman Reese (Cequent)
 PO Box 4050, Dandenong South VIC 3164
 Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100531-WL
RENAULT CAPTUR

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

19. Route the power harness (1) along the LHS of the rear passenger side, past the 'B' pillar trim, towards the front of the vehicle.



20. Continue routing the power harness (1) along the LHS of the passenger's side towards the fuse panel in the glove box.




21. Inside the fuse panel, locate the vacant slot (1) as shown (If there is a fuse, remove and keep). **Note: Due to vehicle variations, if no vacant spot is available, use a multi-meter to locate an existing fuse location that has constant 12V.**

22. Insert the supplied fuse (2) into the upper slot of the add-a-fuse (3).

23. Plug the add-a-fuse (3) into the vacant slot (1) on the fuse panel (if a vehicle fuse had been removed, insert it into the lower slot as shown).

24. Connect the power patch 1-way connector (4) into the add-a-fuse harness mating connector (5).



Issue Date 23-04-15

Page 6

Part No: 100531-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE
PART No: 100531-WL
RENAULT CAPTUR


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

25. Mount the trailer socket (1) to the tow bar mounting bracket using M4 fasteners (not supplied).
26. Route the tail harness (2) across the tow bar towards the LHS of the vehicle and through the previously drilled out hole.
27. Ensure the tail harness grommet is seated correctly and secure in place using a cable (not supplied).



28. Connect the tail harness (tail length 1800mm) 8-way connector (1) to the trailer patch mating 8-way connector (2).



29. Test the trailer wiring harness function using a light board or multi-meter.
30. Secure all harnesses using cable ties (not supplied).
31. Re-fit all removed parts and secure all fasteners, ensuring there are no squeaks or rattles.
32. Place the fitting instructions in the glove box after fitment.

Issue Date 23-04-15

Page 7

Part No: 100531-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au

