



Towbar Fitting Instructions  
To Suit HONDA ODYSSEY 2009  
Part Number HN58L  
Rating 1000 kg

**WARNING:**

1. Do not, drill, cut, weld or otherwise modify the tow bar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.



- 1 Ensure all hardware items have been included
- 2 Remove bumper bar via:
  - a) 4 x 6mm bolts from behind tail gate
  - b) 3 self tapping screws from each wheel arch
  - c) 2 plastic trim buttons from under side rear section of bumper bar
- 3 Remove and discard impact beam and tow eye point
- 4 Fit tow bar into position so as to align with impact beam mounting points and fit bolts supplied as per diagram
- 5 Tighten to torque listing
- 6 Cut bumper as per diagram below
- 7 Refit bumper in reverse of Step 2
- 8 Tow bar rating sticker to be conspicuously located on the inside rear end of the drivers door (**see diagram below**)

**RECOMMENDED ASSEMBLY TORQUE LISTING**

Diameter	Grade 8.8 Bolt	Nm
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8

**FOR TOWING PURPOSES ONLY**  
For towing capacity details please refer to  
vehicle owner's manual or to the manufacturer.  
**Overloading can void your warranties.**

**BUMPER CUT DIAGRAM**




# TRAILBOSS

Towbar Fitting Instructions  
To Suit HONDA ODYSSEY 2009  
Part Number HN58L  
Rating 1000 kg

**NOTE:** Trailboss recommends that you check your towball to ensure it complies with the Australian standard AS 4177.2.

**PLEASE NOTE:** It is advised to remove lug from saddle when not actually towing so as to produce a clear view of the vehicles registration plate if obscured, and to also provide increased departure angle.





Wiring Loom Fitting Instructions  
To Suit Honda Odyssey  
Part Number 100154-WL

## Wiring Loom Installation Instructions

Honda Odyssey  
Part No: 100154-WL

Tail Harness Length Required: 1200mm  
RPA Override Switch Part No: 04848 (If Fitted)

Wiring Loom Installation Time: Approx 30 Mins



Wiring Loom Fitting Instructions  
To Suit Honda Odyssey  
Part Number 100154-WL

1. Remove the rear passenger seat and all the required trims to gain access to the LHS and RHS rear quarter areas of the vehicle.
2. Disconnect the LHS tail light connectors. Patch the Trailer Patch Harness (P/No: 100154-WL) LHS connectors in between the tail light connectors.
3. On the LHS, expose the vehicle harness wires from the corrugated tubing (next to the seat belt mechanism) by removing the tape and splice the Trailer Patch Harness BLACK wire into the vehicle harness RED wire reverse signal.
4. Route the Trailer Harness patch towards the RHS tail light connector. Disconnect the RHS tail light connectors. Patch the Trailer Patch Harness (P/No: 100154-WL) RHS connectors in between the RHS tail light connectors.
5. On the rear RHS of the vehicle, remove the blanking grommet from the grommet hole. From outside of the vehicle, mount the tail harness socket onto the towbar mounting bracket using M4 fasteners (not supplied).
6. Connect the Tail harness connector to the Trailer Patch Harness (100154-WL) mating connector.
7. Test the Trailer Harness function using trailer light board or multimeter.
8. Secure all harnesses to the vehicle using cable ties (not supplied).
9. Refit all removed parts and secure all fasteners.
10. Please place the fitting instructions in the glove box after installation.