

# TRAILBOSS

## Towbar Fitting Instructions To Suit HYUNDAI SANTA FE – DM SERIES Part Number QTHY263L Rating 2500/150 kg


PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED

### **WARNING:**

1. Do not, drill, cut, weld or otherwise modify the tow bar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.
3. The high tensile fasteners supplied with this product were used to achieve the specified rating. If replacement is required ensure that fasteners of the same rating & quality are used. Contact an authorised **Trailboss** dealer if further information is required.
4. If TBM is used in inverted position tow ball may make contact with rear tailgate when lowered, which could cause damage.

### **General:**

1. Ensure all hardware items have been included refer to assembly diagram.
2. It is recommended that the instructions are read through and completely understood before making any attempt to fit this product.
3. Be wary of any changes to vehicle designs or other accessories that may conflict with the installation of this product.
4. Before drilling ensure that the area is clear of fuel, electrical & other components.
5. All holes drilled into the body panels shall have all burrs & swarf removed then coated with a suitable rust preventative paint.
6. For vehicles that require the bumper to be cut. Ensure cut out area is in correct position on the vehicle prior to cutting the bumper.
7. The high tensile fasteners supplied with this product were used to achieve the specified rating. If replacement is required ensure that fasteners of the same rating & quality are used. Contact an authorized **Trailboss** dealer if further information is required.
8. Ensure that all hardware is fastened to torque list below check fasteners on regular basis.
9. Tow bar load rating sticker provided with this product shall be conspicuously located on inside rear end of the driver's door. **(See diagram below).**
10. Trailboss recommends that you check your tow ball to ensure that it complies with the Australian standards **AS 4177.2.**
11. **PLEASE NOTE:** It is advised to remove your lug or tbn when not actually towing so as to produce a clear view of the vehicles registration plate if obscured, and to also provide maximum available departure angle
12. Pull Pin must be fit in down position.



Place load rating sticker  
inside driver's door here

**FOR TRAILER TOWING PURPOSES ONLY**  
For towing capacity details please refer to vehicle owner's  
manual or to the manufacturer. Overloading can void your  
warranties.

### **Tow bar Maintenance and Care.**

Trailboss recommends that bolt torque's, as listed below, are routinely and regularly inspected and checked for correct tension. Replace any worn or defective parts.

We recommended to remove Tow Ball Mounts (TBM's, tongues or lugs) when not being used for any considerable length of time.


So as to avoid injury, when not towing it is suggested that the tongue, Pull Pin and R-clip are removed then stored in a safe, clean and dry place, away from excessive moisture.

Hitch Pull Pins and spring "R" clips are regularly checked for proper installation. Replace any worn or defective parts.

# TRAILBOSS

Towbar Fitting Instructions  
 To Suit HYUNDAI SANTA FE – DM SERIES  
 Part Number QTHY263L  
 Rating 2500/150 kg

PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED



QTY.	DESCRIPTION	ITEM NO.
1	TOWBAR WELDED ASSY	1
1	CLASS 4 TBM ASSY	2
1	BUMPER ADAPTER PASSENGER SIDE	3
1	BUMER ADAPTER DRIVERS SIDE	4
4	WASHER FT M10x25.4x3	5
4	BOLT HEX HD M12x120x1.25P G10.9	6
4	HEX NUT M12x1.25 PC8	7
8	WASHER FLAT 1/2"x1 1/8"x1/8"	8
4	SET SCREW HEX HD M10x35x1.25P	9
12	WASHER FLAT M6x12.5x1.2	10
6	SET SCREW HEX HD M5x20x0.8P	11
6	NUT NYLOC M5-0.8 Z/P	12
1	BUMPER TRIM PINCH WELD 350mm	13
1	ACRYLIC COMPLIANCE LABEL	14
1	WIRING LOOM	15
1	HITCH BOX COLLAR COVER	16
1	SILENT HITCH PIN-SILVER	17
2	10mm "D" SHACKLE	18
1	50mm TOWBALL	19



Towbar Fitting Instructions  
To Suit HYUNDAI SANTA FE – DM SERIES  
Part Number QTHY263L  
Rating 2500/150 kg

PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETED

**INSTRUCTION:**

1. Open boot and remove 2x Screws from the LHS Tail Light. Repeat for RHS.
2. Remove LHS Tail Light and disconnect the Connector. Repeat for RHS.
3. Remove 1x Scrivet from inside the LHS Tail Light Cavity. Repeat for RHS.
4. Remove 4x Screws from inside the LHS Wheel Arch. Repeat for RHS.
5. Remove 4x Screws from underneath of Bumper on the LHS. Repeat for the RHS.
6. Remove 3x Bolts from underneath vehicle on LHS Back Panel. Repeat for RHS.
7. Disconnect the Wiring Connector near the LHS Chassis Rail at the Rear of the vehicle. If fitted, remove reverse Sensor and Rear view Camera Connectors.


Carefully remove Bumper and place in a safe area.

8. Remove Rubber Grommet from underneath of both Chassis Rails. Offer towbar to vehicle. The Towbar will sit on the outer face of the LHS Chassis Rail, and the inner face of the RHS Chassis Rail. Loosely secure the Towbar using the fastener sequence as seen below.

Tighten to the following torque specifications:

- M12 x 120 x 1.25P GR10.9 = 125Nm
- M10 x 35 x 1.25P = 49Nm

9. Remove Impact Beam from Bumper by dislodging 5x Scrivets and Wiring Plugs. Retain 2x Scrivets.
10. Attach Bumper Tab Brackets onto Towbar by using 2x M5 Bolts, 4x M5 Washers, and 2x M5 Nyloc Nuts per side.
11. Identify the centreline of the bumper; perform a bumper cut by measuring the outside of the bumper as per the image shown. Use bumper trim supplied.
12. Re-attach Bumper using steps in 1-7 reverse order. Use two retained Scrivets to attach Bumper to Towbar.



Rev: A

Page 3

Issue Date: 21-01-2016

**Cequent Customer Service**  
Ph: 1800 812 017 Fax: 03 9898 3299  
Email: info@cequent.com.au  
Post: PO Box 4050, Dandenong South VIC 3175



Wiring Loom Fitting Instructions  
To Suit Hyundai Santa Fe DM / DM2 / DM3  
Part Number 100863-WL

**Wiring Loom Installation Instructions**

**Hyundai Santa Fe DM / DM2 / DM3  
Part No: 100863-WL**

**Tail Harness Length Required: 1200mm (DM / DM2),  
1800mm (DM3)**

**Wiring Loom Installation Time: Approx 45 Mins**



Wiring Loom Fitting Instructions  
To Suit Hyundai Santa Fe DM / DM2 / DM3  
Part Number 100863-WL

1. In the luggage compartment, remove the sun shade and the tool compartment cover.
2. Remove the luggage compartment foam tool tray.
3. Remove the plastic tool tray by removing the three screws.
4. Remove the four bolts on the third row passenger seats and the four bolts in front of the third row of the passenger seats.
5. Remove the third row passenger seats from the vehicle.
6. On the LHS of the luggage compartment trim, remove the two screws and one seat belt bolt.
7. Dislodge the LHS luggage compartment trim.

**Repeat steps 6 & 7 for the RHS.**

**Note: On the RHS luggage compartment, 12v power and light connector may need to be disconnected before dislodging.**

8. Dislodge the RHS second row passenger seats to gain access to the RHS side panel trim.
9. Remove the RHS rear door sill trim.
10. On the driver's side, remove the door sill trim.
11. Dislodge the RHS 'B' pillar trim.
12. Underneath the driver's side dash, remove the RHS kick panel trim by first remove the screw on the bonnet lever.
13. On the outside of the vehicle, remove the RHS tail light by first removing the two screws.

## Wiring Loom Fitting Instructions To Suit Hyundai Santa Fe DM / DM2 / DM3 Part Number 100863-WL

### 14. For Santa Fe DM1 and DM2 models only:

On the RHS rear quarter of the vehicle, drill a Ø30mm hole (1). File any rough or sharp edges and spray with rust inhibitor.



### 15. For Santa Fe DM3 models:


Locate the existing vehicle grommet hole and remove the grommet (1). Drill out the grommet hole to Ø30mm. File any rough or sharp edges and spray with rust inhibitor.



16. File any rough or sharp edges and spray with rust inhibitor.

## Wiring Loom Fitting Instructions To Suit Hyundai Santa Fe DM / DM2 / DM3 Part Number 100863-WL

17. On the LHS of the luggage compartment, connect the ezy-tap (1) to the corresponding vehicle wires (2), then connect the trailer patch terminal (3) to the ezy-tap (1).



### Santa Fe DM / DM2 models:

Function	Trailer Patch	Vehicle Connector
L.IND	YELLOW	YELLOW / BLACK
REVERSE	BLACK	RED

### Santa Fe DM3 models:

Function	Trailer Patch	Vehicle Connector
L.IND	YELLOW	GREY

18. Route the trailer harness towards the RHS of the vehicle tail light.
19. On the RHS of the vehicle, from the outside feed the existing vehicle grommet and tail light connector through the grommet hole and into the vehicle.
20. Inside the luggage compartment, feed the trailer harness connector through the grommet hole and connect to the tail light assembly connector.
21. Connect the 2nd trailer harness connector to the mating vehicle connector.

# TRAILBOSS

## Wiring Loom Fitting Instructions To Suit Hyundai Santa Fe DM / DM2 / DM3 Part Number 100863-WL

22. Using a tek screw, secure the ground ring terminal (1) to the sheet metal as shown.



**DM / DM2 models:**



**DM3 models:**

23. Route the 'ORANGE' power wire towards the front of the vehicle along the RHS existing vehicle harness.

24. Continue routing the 'ORANGE' power wire, past the 'B' pillar trim and the driver's side door sill towards the front of the vehicle.

25. Continue routing the 'ORANGE' power wire up through the kick panel area towards the fuse panel.

26. Inside the fuse panel, locate the 20-amp (1) fuse as shown and discard.


27. Insert the supplied 20-amp fuse (2) into the lower slot of the add-a-fuse (3) and insert the supplied 30-amp fuse (3) into the upper slot of the add-a-fuse (4).

28. Plug the add-a-fuse (4) into the previously removed 20-amp fuse slot.



## Wiring Loom Fitting Instructions To Suit Hyundai Santa Fe DM / DM2 / DM3 Part Number 100863-WL

29. Connect the power patch 1-way connector (5) into the add-a-fuse harness mating connector (6).



30. Mount the tail harness (DM / DM2: 1200mm, DM3: 1800mm) trailer socket to the tow bar mounting bracket using M4 fasteners (not supplied).
31. Route the tail harness across the tow bar towards the LHS of the vehicle and up through the previously drilled out hole.
32. Ensure the tail harness grommet is seated correctly and secure in place using a cable tie (not supplied).
33. Connect the tail harness (tail length 1200mm) 8-way connector to the trailer patch mating 8-way connector.
34. Test the trailer patch function using a light board or multi meter.
35. Secure all harnesses using cable ties (not supplied).
36. Re-fit all removed parts and secure all fasteners, ensuring there are no squeaks or rattles.
37. Place the fitting instructions in the glove box after fitment.
38. The RPA function can be disabled via the switch on the dash panel.



# FITTING INSTRUCTIONS

## Silent Anti-Rattle Hitch Pin (PR0001)

• These fitting instructions are supplied to ensure understanding of how the HITCH PIN should be fitted and used correctly.

• Once installed, we recommend **ALL** instructions are kept and placed in the vehicle glove box.

**NOTE: Routine maintenance and inspection of the towbar & HITCH PIN is required. Regularly inspect for wear and check the tightness of the Hitch Pin. Follow instructions below to retighten the nut when necessary.**

**\*Do not tow with your vehicle if the R CLIP or the HITCH PIN is loose or missing. Replacement parts are available from your Pro Series Distributor.**




Fig 1. Silent Anti-Rattle Hitch Pin assembly

### STEP 1

Insert Trailer Ball Mount (TBM) into towbar HITCHBOX, aligning hole in TBM SHANK with hole in HITCHBOX (Fig 2).




Fig 2. Installation of Trailer Ball Mount




Fig 3. Silent Anti-Rattle Hitch Pin orientation

### STEP 2

Insert HITCH PIN through hole in HITCHBOX and hole in TBM SHANK; ensure the LOCATORS are inserted into the NOTCHES in the HITCHBOX (Fig. 3).

### STEP 3

Screw HITCH PIN NUT onto HITCH PIN; tighten HITCH PIN NUT until finger tight, ensuring TBM is restrained from movement.

### STEP 4

Tighten HITCH PIN NUT by turning nut a further 1/8th of a turn in the clockwise direction using a 24mm spanner (Fig. 4).

### STEP 5

Install HITCH PIN R CLIP through the hole on the HITCH PIN (Fig. 1).




Fig 4. Tightening of Silent Anti-Rattle Hitch Pin Nut